

FLAMMABLE SAFETY STORAGE CABINET

Safe storage flammable chemicals in order to reduce the risk of fire, and to protect staffs and equipment; Even in a narrow working space, the small flammable cabinet also can provide safe storage for your combustible, flammable liquids and chemicals.

Call now! +86-13302388256



FIREPROOF CHEMICAL CABINET STANDARD SPECIFICATION

4 Gallon	430*430*560mm	1 adjustable shelf	single door	manual close or self-closing
12 Gallon	590*460*890mm	1 adjustable shelf	single door	manual close or self-closing
30 Gallon	1090*460*1120mm	1 adjustable shelf	double door	manual close or self-closing
45 Gallon	1090*460*1650mm	2 adjustable shelves	double door	manual close or self-closing
60 Gallon	860*860*1650mm	2 adjustable shelves	double door	manual close or self-closing
90 Gallon	1090*860*1650mm	2 adjustable shelves	double door	manual close or self-closing
110 Gallon	1500*860*1650mm	2 adjustable shelves	double door	manual close or self-closing

Phone: +86-13302388256

Email: info@zhlabsfurniture.com

Address: No.3068, Liangsha Road, Chendong Village, Zhongluotan Town, Baiyun District, Guangzhou City, Guangdong Province, China

FLAMMABLE LIQUID STORAGE CABINET ADVANTAGES

- 1.0mm cold rolled steel body, all welded double wall construction with 38mm (1 11/2") insulating air space to keep less temperature when outside get burned;
- 50mm leak proof sump to catch incidental drips;
- Piano hinges, the doors can be opened 180 degree freely;
- lockable flush mounted handle with 2 keys;
- Three-point latch with a manual lock for better security;
- Two flame arrester vents;
- Adjustable galvanized steel shelves, 1.0mm thickness with reinforce for heavy duty;
- Safety signage in high visibility reflective labels;
- Epoxy powder coated with yellow finish; Adjustable leveling feet and grounding connector;
- Meets OSHA, and NFPA code 30;
- Red and blue color available; (red indicates combustible liquid; blue indicates corrosive liquid)
-



FLAMMABLE LIQUIDS CABINET APPLICATION

- Yellow-Flammable Liquid Cabinet, used to store Ethyl alcohol, Glue, Diethyl ether, Petrol, Kerosene, Raw petroleum, Benzene, Banana oil, and so on;
- Red-Combustible Liquid Cabinet, used to store Carbon monoxide, Methane, Propane, Ethylene, Aerosol, Ink and coating and so on;
- Blue-Corrosive Liquid Cabinet, used to store Sulfuric oil, bleaching water, Circuit board cleaning agent, Formaldehyde, Alkyl sulfate and so on;
- Green- Pesticide Storage Cabinet, provides professional storage of pesticide.